

# Polaris RZR XP 1000 - Rear Panel



## Product Instructions | Part No: 2792

**Application:** Verify accessory fitment at Kolpin.com.


**Before You Begin:** Read these instructions and check to be sure all parts are accounted for. If any items are missing, do not return to the store. Call us at 1-877-956-5746 for assistance. Please retain these instructions for future reference and parts ordering information.

**Dealers:** Provide Instruction Manual to customer at time of purchase.

**Tools Required:** 4mm Hex Wrench or Socket, Torque Wrench

### Product Contents:

Item	Description	Qty	Part Number
1	Rear Windshield Panel	1	K100137 (Qty 3)
2	Clamp - 1.75" Diameter	6	
3	M6 x 18mm Button Head Screw	18	
4	M6 Lock Washer	18	
5	M6 Domed Shoulder Washer	12	
6	Rubber Clamp Spacer ** Flat Pad - Differ to the image	3	K100189 (Qty 2)
7	1/8" Edge Seal - 35"	1	K100459 (Qty 1)
8	1/8" Edge Seal - 9"	1	



Kolpin Outdoors, Inc. | 9955 59th Ave N | Plymouth, MN 55442


(877) 956-5746 or (763) 478-5800 | [www.kolpin.com](http://www.kolpin.com) | [customerservice@kolpin.com](mailto:customerservice@kolpin.com)

**Assembly Time:** Approximately 25 minutes

**Important:** This product is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean, free of debris and has no Roof - install it before assembling the Roof. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

### Installation Instructions:

1. Shift vehicle transmission into PARK. Turn key to OFF position and remove from vehicle.
2. Remove the Rear Windshield Panel from the box and place it on a clean flat surface that won't scratch the Windshield. The panel is protected by film on both sides. To prevent scratching to the panel during assembly, only peel back the protective film in areas where the mounting components attach.
3. From the bottom, peel away roughly 1" of the film on both sides of the Rear Windshield Panel. Install items 7 (3/16" Edge Seal—35") and 8 (3/16" Edge Seal—9") and place the Rear Windshield Panel onto vehicle between the top and bottom rear crossmembers of the rear ROPS. See Illustration 1-1.
4. Remove the protective film from both sides of the panel past just the lower clamp mounting holes. Install three clamps (item 2) along with the spacers (item 6), with the Kolpin logos facing down, onto the lower rear crossmember. Use fastener items 3 (M6 x 18mm Button Head Screw) and 4 (M6 Lock Washer) and fasten loosely. See Illustration 1-2.
5. Align all the threaded holes of the lower three clamps to the lower clamp holes on the Rear Windshield Panel and install fastener items 3 (M6 x 18mm Button Head Screw), 4 (M6 Lock Washer), and 5 (M6 Domes Shoulder Washer), and fasten loosely. See Illustration 1-3.




Kolpin Outdoors, Inc. | 9955 59th Ave N | Plymouth, MN 55442

(877) 956-5746 or (763) 478-5800 | [www.kolpin.com](http://www.kolpin.com) | [customerservice@kolpin.com](mailto:customerservice@kolpin.com)

- Remove the protective film from both sides of the panel completely. Install three clamps (item 2, no spacers inside), with the Kolpin logos facing up, onto the upper rear cross-member. Use fastener items 3 (M6 x 18mm Button Head Screw) and 4 (M6 Lock Washer) and fasten loosely. Align all the threaded holes of the upper three clamps to the upper clamp holes on the Rear Windshield Panel and install fastener items 3 (M6 x 18mm Button Head Screw), 4 (M6 Lock Washer), and 5 (M6 Domes Shoulder Washer), and fasten loosely.

See Illustration 1-4.



- Adjust the Rear Windshield Panel to the most centered position that leaves an even amount of gap between panel and ROPS. Tighten and torque all m6 fasteners (item 3) to the specification below.

See Illustration 1-5.



- Re-inspect hardware tightness before and after riding or trailering.



# DANGER



## TO AVOID SERIOUS INJURY OR DEATH:

1. DO NOT TRAILER VEHICLE FACING REARWARD WITH WINDSHIELD INSTALLED. AIRFLOW MAY CAUSE WINDSHIELD TO SEPARATE FROM VEHICLE, RESULTING IN AN ACCIDENT AND SEVERE INJURY OR DEATH. REMOVE WINDSHIELD OR TRANSPORT VEHICLE IN ENCLOSED TRAILER.
2. UTVs ARE TO ONLY BE DRIVEN WITH CLEAN WINDSHIELDS FOR DRIVING VISIBILITY. IF DIRT OR DEBRIS ACCUMULATES ON THE WINDSHIELD WHEN RIDING, STOP THE UTV AT THE NEXT SAFE LOCATION ON THE TRAIL TO CLEAR OFF THE WINDSHIELD BEFORE YOU RESUME RIDING.
3. ONLY INSTALL WINDSHIELDS THAT ARE DESIGNED FOR THE MAKE AND MODEL OF THE UTV. INSTALLATION OF A WINDSHIELD THAT WAS NOT DESIGNED FOR THE UTV MAKE AND MODEL CAN IMPACT WINDSHIELD DURABILITY AND PERFORMANCE.
4. READ AND UNDERSTAND WINDSHIELD INSTRUCTION SHEETS AND UTV OWNER MANUAL BEFORE WINDSHIELD INSTALLATION OR OPERATING THE VEHICLE.
5. PERIODICALLY CHECK FOR WEAR AND TIGHTNESS OF ALL FASTENERS. ALWAYS INSPECT BEFORE AND AFTER RIDING OR TRAILERING. REPLACE OR RE-TORQUE FASTENERS AS NECESSARY.

## Windshield Cleaning Information:

- Remove all dirt, mud, dust and debris from Windshield with water before cleaning.
- Use a mild soap or dishwashing detergent along with a soft sponge or soft cotton cloth to clean Windshield surface. Do not apply in direct sunlight. Rinse with water immediately and dry with a soft cotton cloth or chamois.
- Always test cleaning agents in a small inconspicuous area prior to cleaning entire panel.
- Never use Windshield cleaning fluids (409, Windex, etc.), gasoline, high alkaline cleaners, or solvents.
- Never use abrasives, brushes, razor blades, scrapers, squeegees, gloves or dirty cloths.

For additional assistance, please contact Kolpin customer service department at  
(877) 956-5746 or (763) 478-5800 or email [customerservice@kolpin.com](mailto:customerservice@kolpin.com).

## One Year Limited Warranty

For the period of one (1) year from the purchase date, Kolpin will replace for the original purchaser, free of charge, any part or parts found upon examination by Kolpin to be defective in material, workmanship, or both.

All transportation costs incurred submitting product to Kolpin for warranty consideration must be borne by the purchaser. If Kolpin determines that the product must be returned to the factory for credit, please call 1-877-956-5746 for a Return Merchandise Authorization (RMA) number and shipping instructions.

This warranty does not apply to parts that have been damaged by accident, alteration, abuse, improper maintenance, normal wear, or other causes beyond the manufacturer's control. In order to protect you and your ATV, certain parts of the accessory system and/or hardware are designed to fail when the equipment is over-stressed. Parts that are lost due to loosening and improper maintenance are not covered under warranty. This warranty does not cover removal or reinstallation labor fees of the plow system and related components.

Peripheral products such as engines, electric motors, and actuators may carry an original manufacturer's warranty. Most hardware is general in nature and is easily obtained locally. Be sure to replace with minimum metric class 8.8 specification.