

MAP BAG KIT

P/N 2879706



Application

MY14 AND NEWER SPORTSMAN ACE MODELS

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Contents:

<u>Qty</u>	<u>Part Description</u>	<u>Part Number</u>
1	Map Bag	2879706
1	Instructions	9924927

APPROXIMATE ASSEMBLY TIME: 02 minutes

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence as shown on the attached instructions. Do not carry sharp, pointed, or heavy objects as they can damage the bag. Maximum bag capacity is 2 lbs.

INSTALLATION INSTRUCTIONS:

1. Place the bag on the overhead ROPS tubes from front to back. The zippered pouch should be placed forward for easy access while sitting in vehicle.
2. Securely wrap the velcro straps around the left hand and right hand ROPS tubes. Figure 1.

