

OUTLAW 70 DECAL KIT



P/N 2885107

APPLICATION


Verify accessory fitment at www.polaris.com.

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.


KIT CONTENTS

FRONT FENDER TOP DECALS




| REF | QTY | PART DESCRIPTION | P/N AVAILABLE SEPARATELY |
|-----|-----|---|--------------------------|
| 1 | 1 | DECAL-FRONT FENDER, TOP, LEFT SIDE | 7193992 |
| 2 | 1 | DECAL-FRONT FENDER, TOP, MID, LOWER LEFT SIDE | 7193948 |
| 3 | 1 | DECAL-FRONT FENDER, TOP, MID, UPPER LEFT SIDE | 7193950 |
| 4 | 1 | DECAL-FRONT FENDER, TOP, CENTER, LEFT SIDE | 7193952 |
| 5 | 1 | DECAL-FRONT FENDER, TOP, CENTER, FRONT LEFT SIDE | 7193954 |
| 6 | 1 | DECAL-FRONT FENDER, TOP, CENTER, REAR LEFT SIDE | 7193956 |
| 7 | 1 | DECAL-FRONT FENDER, TOP, SIDE, RIGHT SIDE | 7193993 |
| 8 | 1 | DECAL-FRONT FENDER, TOP, MID, LOWER RIGHT SIDE | 7193949 |
| 9 | 1 | DECAL-FRONT FENDER, TOP, MID, UPPER RIGHT SIDE | 7193951 |
| 10 | 1 | DECAL-FRONT FENDER, TOP, CENTER, RIGHT SIDE | 7193953 |
| 11 | 1 | DECAL-FRONT FENDER, TOP, CENTER, FRONT RIGHT SIDE | 7193955 |
| 12 | 1 | DECAL-FRONT FENDER, TOP, CENTER, REAR RIGHT SIDE | 7193957 |

FRONT FENDER REAR DECALS




| REF | QTY | PART DESCRIPTION | P/N AVAILABLE SEPARATELY |
|-----|-----|--|--------------------------|
| 13 | 1 | DECAL-FRONT FENDER, REAR, LEFT SIDE | 7193958 |
| 14 | 1 | DECAL-FRONT FENDER, REAR, MID, LEFT SIDE | 7193960 |
| 15 | 1 | DECAL-FRONT FENDER, REAR, CENTER, FRONT, LEFT SIDE | 7193962 |
| 16 | 1 | DECAL-FRONT FENDER, REAR, SIDE, LOWER, LEFT SIDE | 7193964 |
| 17 | 1 | DECAL-FRONT FENDER, REAR, LEFT MID, LOWER, LEFT SIDE | 7193966 |
| 18 | 1 | DECAL-FRONT FENDER, REAR, MID, LOWER, LEFT SIDE | 7193968 |
| 19 | 1 | DECAL-FRONT FENDER, REAR, RIGHT MID, LOWER, LEFT SIDE | 7193970 |
| 20 | 1 | DECAL-FRONT FENDER, REAR, CENTER, MID, LEFT SIDE | 7193972 |
| 21 | 1 | DECAL-FRONT FENDER, REAR, CENTER, REAR, LEFT SIDE | 7193974 |
| 22 | 1 | DECAL-FRONT FENDER, REAR, SIDE, RIGHT SIDE | 7193959 |
| 23 | 1 | DECAL-FRONT FENDER, REAR, MID, RIGHT SIDE | 7193961 |
| 24 | 1 | DECAL-FRONT FENDER, REAR, CENTER, FRONT, RIGHT SIDE | 7193963 |
| 25 | 1 | DECAL-FRONT FENDER, REAR, SIDE, LOWER, RIGHT SIDE | 7193965 |
| 26 | 1 | DECAL-FRONT FENDER, REAR, LEFT MID, LOWER, RIGHT SIDE | 7193967 |
| 27 | 1 | DECAL-FRONT FENDER, REAR, MID, LOWER, RIGHT SIDE | 7193969 |
| 28 | 1 | DECAL-FRONT FENDER, REAR, RIGHT MID, LOWER, RIGHT SIDE | 7193971 |
| 29 | 1 | DECAL-FRONT FENDER, REAR, CENTER, MID, RIGHT SIDE | 7193973 |
| 30 | 1 | DECAL-FRONT FENDER, REAR, CENTER, REAR, RIGHT SIDE | 7193975 |

REAR FENDER TOP DECALS



| REF | QTY | PART DESCRIPTION | P/N AVAILABLE SEPARATELY |
|-----|-----|---|--------------------------|
| 31 | 1 | DECAL-REAR FENDER, TOP, LEFT SIDE | 7193976 |
| 32 | 1 | DECAL-REAR FENDER, TOP, LEFT MID, LEFT SIDE | 7193978 |
| 33 | 1 | DECAL-REAR FENDER, TOP, MID, LOWER, LEFT SIDE | 7193980 |
| 34 | 1 | DECAL-REAR FENDER, TOP, MID, UPPER, LEFT SIDE | 7193982 |
| 35 | 1 | DECAL-REAR FENDER, TOP, CENTER, UPPER, LEFT SIDE | 7193984 |
| 36 | 1 | DECAL-REAR FENDER, TOP, SIDE, RIGHT SIDE | 7193977 |
| 37 | 1 | DECAL-REAR FENDER, TOP, RIGHT MID, RIGHT SIDE | 7193979 |
| 38 | 1 | DECAL-REAR FENDER, TOP, MID, LOWER, RIGHT SIDE | 7193981 |
| 39 | 1 | DECAL-REAR FENDER, TOP, MID, UPPER, RIGHT SIDE | 7193983 |
| 40 | 1 | DECAL-REAR FENDER, TOP, CENTER, UPPER, RIGHT SIDE | 7193985 |

REAR FENDER FRONT / SIDE DECALS



| REF | QTY | PART DESCRIPTION | P/N AVAILABLE SEPARATELY |
|-----|-----|--|--------------------------|
| 41 | 1 | DECAL-REAR FENDER, FRONT, LEFT SIDE | 7193988 |
| 42 | 1 | DECAL-REAR FENDER, FRONT, CENTER, LEFT SIDE | 7193990 |
| 43 | 1 | DECAL-REAR FENDER, SIDE, REAR, LEFT SIDE | 7193986 |
| 44 | 1 | DECAL-REAR FENDER, FRONT, RIGHT SIDE | 7193989 |
| 45 | 1 | DECAL-REAR FENDER, FRONT, CENTER, RIGHT SIDE | 7193991 |
| 46 | 1 | DECAL-REAR FENDER, SIDE, REAR, RIGHT SIDE | 7193987 |

TOOLS REQUIRED

- Heat Gun (or equivalent)
- Low Friction Squeegee Sleeve
- Plastic Applicator (Squeegee)

CONSUMABLES REQUIRED

- Adhesive Remover (Goo Gone® or 3M™ Citrus Base)
- Cloth, Non-Abrasive (Cheesecloth or equivalent)
- Isopropyl Alcohol (IPA)

IMPORTANT

Your Outlaw 70 Decal Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

VEHICLE PREPARATION

ENVIRONMENTAL REQUIREMENTS

- Apply decals indoors or in a location free from dust and dirt.
- Decals must reach room temperature prior to application.
- The temperature must be between 40° to 100° F (4° to 38° C).

NOTICE

Decals above or below these temperatures may not adhere to the surface properly. Humidity should also be taken into consideration.

- Decals must cure for 72 hours after application.

GENERAL

1. Locate the existing decals on the front and rear fenders.
2. Lift up on the edge of each decal and slowly pull the decal away from the vehicle's surface.

IMPORTANT

Do not remove the front or rear fender reflectors.

3. If necessary, remove the residual adhesive with Goo Gone® or a similar adhesive remover.
4. Clean the residue from the adhesive remover with a lint-free cloth dampened with isopropyl alcohol.

ACCESSORY INSTALLATION

TIP


- Apply the large decals first. Then apply the small decals.
- To strengthen the bond between the decal and the vehicle's surface, apply heat to the vehicle's surface before you install each decal.

INSTALLATION – FRONT FENDER TOP DECALS

1. Clean the front fender with a lint-free cloth dampened with isopropyl alcohol.
2. Locate the Front Fender Top Left Side decals (labeled ① through ⑥ under Kit Contents).

NOTICE

The P/N is included on each decal tab.



3. Apply a heat gun (or equivalent) to the surface of the vehicle where the first decal will be installed.

IMPORTANT

Do not heat the surface for more than one to two seconds.

4. Lay the decal graphic side down on a clean, flat surface.
5. Place your finger over the liner on the back of the decal and peel back the liner at a 180° angle.

IMPORTANT

Do not place your finger on the corner or edge of the adhesive. Contamination may prevent the decal from adhering to the surface properly.

6. Gently apply the entire decal to the surface. Using a squeegee, continue to press the decal into place working from the center of the decal outwards.
7. You can reposition the decal if it is not completely pressed onto the surface. If necessary, reposition the decal to allow air bubbles to escape. Then, gently reapply the decal to the surface.
8. Peel back the transfer tape on the front of the decal at a 180° angle.


If you loosen any of the outside edges, gently reapply the squeegee or your finger over the surface of the exposed decal.

9. Check the decal for imperfections.

If you see air bubbles, use the squeegee or your finger and press firmly to work the air bubbles to the outside edges.


10. Let the decals cure for 72 hours after application.

11. Repeat these steps for the Front Fender Top Right Side decals (labeled ⑦ through ⑫ under Kit Contents).




INSTALLATION – FRONT FENDER REAR DECALS

1. Clean the front fender with a lint-free cloth dampened with isopropyl alcohol.
2. Locate the Front Fender Rear Left Side decals (labeled ⑬ through ⑳ under Kit Contents).



3. Repeat steps 3 through 10 under **INSTALLATION – FRONT FENDER TOP DECALS**.


4. Locate the Front Fender Rear Right Side decals (labeled ㉒ through ㉓ under Kit Contents).



5. Repeat steps 3 through 10 under **INSTALLATION – FRONT FENDER TOP DECALS**.

INSTALLATION – REAR FENDER TOP DECALS

1. Clean the rear fender with a lint-free cloth dampened with isopropyl alcohol.
2. Locate the Rear Fender Top Left Side decals (labeled 31 through 35 under Kit Contents). The P/N is included on each decal tab.



3. Apply a heat gun (or equivalent) to the surface of the vehicle where the first decal will be installed.

IMPORTANT

Do not heat the surface for more than one to two seconds.

4. Lay the decal graphic side down on a clean, flat surface.
5. Place your finger over the liner on the back of the decal and peel back the liner at a 180° angle.

IMPORTANT

Do not place your finger on the corner or edge of the adhesive. Contamination may prevent the decal from adhering to the surface properly.


6. Gently apply the entire decal to the surface. Using a squeegee, continue to press the decal into place working from the center of the decal outwards.
7. You can reposition the decal if it is not completely pressed onto the surface. If necessary, reposition the decal to allow air bubbles to escape. Then, gently reapply the decal to the surface.
8. Peel back the transfer tape on the front of the decal at a 180° angle.

If you loosen any of the outside edges, gently reapply the squeegee or your finger over the surface of the exposed decal.

9. Check the decal for imperfections.


If you see air bubbles, use the squeegee or your finger and press firmly to work the air bubbles to the outside edges.

10. Let the decals cure for 72 hours after application.
11. Repeat these steps for the Rear Fender Top Right Side decals (labeled 36 through 40 under Kit Contents).




INSTALLATION – REAR FENDER FRONT / SIDE DECALS

1. Clean the rear fender with a lint-free cloth dampened with isopropyl alcohol.
2. Locate the Rear Fender Front / Left Side decals (labeled ④① through ④③ under Kit Contents).



3. Repeat steps 3 though 10 under **INSTALLATION – REAR FENDER TOP DECALS.**

4. Locate the Rear Fender Front / Right Side decals (labeled ④④ through ④⑥ under Kit Contents).



5. Repeat steps 3 though 10 under **INSTALLATION – REAR FENDER TOP DECALS.**

INSTRUCTION FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

