

SADDLEBAG FITTED BAG KIT



P/N 2880294

APPLICATION

ALL INDIAN TOURING MOTORCYCLES WITH HARD SADDLEBAGS

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for in package. Please retain these installation instructions for future reference and parts ordering information.



KIT CONTENTS

Ref	Qty	Part Description	Part Number
1	2	Fitted Saddlebag Bag	2686184
	1	Instructions	9925242

APPROXIMATE ASSEMBLY TIME

5 min

IMPORTANT

Your Polaris SADDLEBAG FITTED BAG KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

1. Remove fitted bags from packaging.
2. Place one bag (1) in each hard saddlebag (A).

CAUTION: Ensure zippers and handles will not be caught in the saddlebag lid before closing saddlebag lid.

CAUTION: Do not leave these bags in direct sunlight for long periods of time. Do not leave these bags in moist areas.

These bags are made with natural cotton and leather materials and will age more quickly if not treated with care.

