

**FRONT BUMPER
ACCESSORY PN 2878709**



If your Sportman XP doesn't have a front integrated winch, follow those additional instructions.

Contents of the kit:

Ref.	Description	Qty
01	Spacer	2
02	M8 x 80 mm hex. flanged bolt	2

1. At step 4 of the bumper main instructions, use the spacers **01** and the supplied bolts **02** in this kit to attach the lower bracket of the bumper to the vehicle as indicated in the illustration.
2. Follow the rest of the bumper main instruction.

