

REVERSE WARNING KIT

P/N 2876228



POLARIS
The Way Out.®

Application

RANGER 10 Series; 2005-2012 RANGER; RANGER EV; RANGER 900 XP
(For RANGER Diesel use PN 2898526)

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This Kit Includes:

<u>Qty.</u>	<u>Part Description</u>	<u>Part No</u>
1	Alarm Beeper	4011808
1	Bracket Mount	5245690
2	Screw	7512297
2	Nut	7542151
1	Instructions	9917124

Tools Required:

Torx Driver Set
7/16" Wrench or Socket
5/16" Drill Bit (for RANGER MY 2005-2008)

IMPORTANT: Your Polaris RANGER reverse warning kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris. Approximate installation time: 15 minutes.

INSTALLATION INSTRUCTIONS

1. **For Series 10:** Using the two screws and nuts supplied with the kit, secure the mount bracket to the cargo box latch point on the driver's side as illustrated. Figure 1.

For RANGER MY 2005-2008: Use the mounting bracket as a template to drill two 5/16" holes in the frame, as illustrated. Make sure that existing electrical wires will reach the alarm beeper. Figure 2.

For RANGER MY 2009 and Newer: Reverse beeper can be secured directly to wire harness using plastic cable ties or secured as shown in Figure 2.

2. Remove the nut that comes with the alarm. Using this nut, secure the alarm to the mount bracket with wires to the front.
3. Locate the red/white purple wires with black terminal ends near the alarm. **NOTE:** The wires may need to be pulled from the harness tubing to reach the alarm.
4. Connect the red/white wire to the terminal marked "+" on the alarm.
5. Connect the purple wire to the terminal marked "--" on the alarm.
6. Turn on the ignition key and put the vehicle into reverse gear to test the alarm.

