

CHAIN DRIVEN ATV HITCH KIT KIT PN 2873036



Application:

All 1990 and newer chain driven ATVs

Before you begin, read these instructions and check to be sure all parts and tools are accounted for.

Please retain these installation instructions for future reference and parts ordering information.

The contents of this kit include:

<u>Qty.</u>	<u>Part Description</u>	<u>Part No.</u>
1	Hitch	1040294-067
1	Decal, Hitch	7072533
2	Bolt	7512576
2	Nut	7542522
2	Washer	7555883
1	Instructions	9912609

NOTE: Decals are installed on the hitch from the factory.

You will need to supply:

Standard Socket Set Torque Wrench

IMPORTANT: Perform all items correctly and completely.

INSTALLATION INSTRUCTIONS

ON VEHICLES WITH EXISTING HITCHES:

1. Remove two bolts attaching hitch to vehicle and remove hitch. Discard old hitch and fasteners.

ON VEHICLES WITHOUT HITCHES:

2. Remove two bolts holding axle housing to swing arm weldment and discard.

ALL VEHICLES:

3. Using the illustration for reference, place hitch (PN 1040294-067) over top and bottom of swing arm weldment brackets which hold axle housing in place.
4. Insert bolt (PN 7512576) through top of hitch, swing arm weldment and bottom of hitch.
5. Install nut (PN 7542522) and washer (PN 7555883). Torque to 40 ft./lbs.
6. Repeat for second bolt and nut.

