



## Polaris Rhino Grip Instruction Manual

### P/N 2881513

REF	PART DESCRIPTION	QTY
1	Rhino Grip XL	2
2	Rhino Grip Base	2
3	Kwik Clip	2
4	Nylon Washer	2
5	Rubber Expander	2
6	Threaded Rod	2
7	Rubber Strap	2
8	Thumb Screw	2

**ASSEMBLY:**

1. Place the rubber expander on the threaded rod. Place the nylon washer on top of the rubber expander and thread the rod into the threaded insert in the bottom of the base.  
NOTE: The rubber expander for both systems has a counter-bored relief that mates to the threaded rod. Please be sure to install correctly!
2. Place the expander in the Lock & Ride® hole on the bed rail and twist the base clockwise. As you twist the threaded rod will compress the rubber expander and secure the grip to your Sportsman ATV Rack.
3. Place the Rhino Grip into the base, orient the grip as desired and secure with the Kwik Clip.
4. To remove, simply turn the base counter clockwise and remove from the ATV Rack.

