

COIL SPRING SPACER KIT KIT PN 2872655



Application

All Polaris ATVs

Before you begin, read these instructions and check to be sure all parts and tools are accounted for.

Please retain these installation instructions for future reference and parts ordering information.

The contents of this kit include:

<u>Qty.</u>	<u>Part Description</u>	<u>Part No.</u>
2	Spacer, Coil	5411763
1	Instruction	9915945

You will need to supply:

Standard Jack
Dishwashing Soap

IMPORTANT: Perform all items correctly and completely.

INSTALLATION INSTRUCTIONS

1. Place ATV on level terrain and apply parking brake.
2. When installing front spacers, jack up the front of machine just enough to take the pressure off the front springs. If spacers are being used at the rear, jack up the rear just enough to take the pressure off the rear springs.
3. Lubricate spacers by coating them with dishwashing soap. Install spacers between coils. Spacers should be positioned in center of coils.

NOTE: Always install an equal number of spacers on the left-hand and right-hand sides of the ATV.

PN 9915945 Rev 01 8/99
Printed in U.S.A.