BRAKE DISC AND PAD KIT KIT P/N 2201894, 2201895, 2201896, 2201897, 2201898



Application

2201894 - 1998-2000 Sportsman 335 and Sportsman 500 2201895 - 1999/2000 Magnum 500 and 2000 Xpedition 425

2201896 - 2000 Magnum 325 2x4 and 4x4, 2000 Trail Boss, 1999/2000 Trail Blazer, 2000 Xplorer SP,

1997-2000 Scrambler 500, 1997-2000 Scrambler 400, 2000 Xpedition 325

2201897 - 2000 Xplorer 400 2201898 - 2000 500 6x6

IMPORTANT: Due to the technical nature of this kit, Polaris insists that the installation be performed by a Certified Polaris Technician.

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

Quantity	Description	Part Numbers Per Kit				
		2201894	2201895	2201896	2201897	2201898
2	Front Brake Disc	5243676	5243676	5246832	5243676	5243676
1	Rear Disc Assy	1910440	5243678	5243678	5243679	5244425
4	Front Brake Pad Assembly	1910678	1910678	1910678	1910678	1910678
1	Rear Brake Pad Kit	2202411	2202411	2202411	2202411	1910450
8	Bolt	7512325	7512325	7512325	7512325	7512325
3	Bolt *		7515481	7515481		
3	Nut *			7542439	7542439	7542439
1	Instructions	9916967	9916967	9916967	9916967	9916967

IMPORTANT: Perform all items correctly and completely.

INSTALLATION INSTRUCTIONS

1. Keep the discs and pads free of contaminants. Follow procedures as outlined in the Master Repair Manual to install the new discs and pads.

NOTE: Loctite 242® is recommended for use on the Magnum and Xpedition rear disc hardware.

- * Concentric drive models must use nut to retain rear disc.
- * Magnum / Xpedition models must use bolt to retain rear disc.

P/N 9916967 Rev 05 06/03 Printed in U.S.A.