

DUST COVER KIT



SLINGSHOT

P/N 2880660, 2882415

APPLICATION

All Slingshot® models
Verify fitment at polarisslingshot.com.



BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

INSTALLATION VIDEO

The video is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

KIT CONTENTS

REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	Slingshot® Dust Cover (2880660) Sunshade Dust Cover (2882415)	- -
	1	Instructions	9961080

ASSEMBLY TIME

Approximately 6 minutes

IMPORTANT

Your Dust Cover Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

1. Shift vehicle transmission to NEUTRAL. Turn key to OFF position and remove from vehicle.
2. Remove any accessories that may interfere with installing dust cover.

Apply parking brake.

NOTE

Ensure any sharp objects are removed to prevent puncturing dust cover.

3. Drape cover over vehicle. Front of cover is identified with Slingshot® logo.



4. Pull bottom edge of dust cover down over tires as far as possible. Ensure cover is even on all sides of vehicle.

⚠ WARNING

Do not use accessory while trailering vehicle.

FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

FEEDBACK FORM

