

Tether Install on ProRide/ AXYS Snowmobiles CFI/H.O. Engines

Models Included: Pro Ride/ AXYS Machines with CFI/H.O. engines

Inquiry: Where do I plug the Tether Switch onto the Harness?

Response: The kit instructions are out of date for 2874379. Please review the drawings and below for Tether Switch Connection locations on these machines.

Note: ProRide/ AXYS chassis machines wire color is BK and BK/ DB.

