

# AXYS PRO-FIT PRO-TAPER HANDLEBAR BAG KIT

P/N 2880971



## APPLICATION

All AXYS Platforms

## BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

## KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	AXYS Pro-Fit Pro-Taper Handlebar Bag	2880971
	1	Instructions	9925950

## TOOLS REQUIRED

- No Tools Required

## IMPORTANT

Your AXYS PRO-FIT PRO-TAPER HANDLEBAR BAG KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

## ASSEMBLY TIME

Approximately 2 minutes

### IMPORTANT

- Do not carry sharp or pointed objects inside the bag.
- Maximum carrying capacity is 8 lbs. (3.63 Kg).

## INSTALLATION INSTRUCTIONS

1. Unstrap the front of bag ① from the rear.



2. Insert Velcro strips through the mountain grab bar for a Pro-Taper handlebar application or place over handlebar for straight bar application.

3. Re-strap the Velcro strips (A) and (B) to the designated areas on the rear of the bag ①.



### NOTE

Handle bar bag ① is intended to go on the out side of brake line (C) as shown.

