# **EVO™ TUNNEL BAG**





# **APPLICATION**

Verify accessory fitment at Polaris.com.

## **BEFORE YOU BEGIN**

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

#### KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	EVO Tunnel Bag	2883761
	1	Instructions	9928793

## **TOOLS REQUIRED**

None

#### **IMPORTANT**

Your EVO™ Tunnel Bag is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

#### **ASSEMBLY TIME**

Approximately 6 minutes

#### **NOTE**

Additional time may be required for optional steps, or to accommodate other installed accessories.

## INSTALLATION INSTRUCTIONS

1. Turn key to "OFF" position and remove from vehicle.

#### **IMPORTANT**

Ensure vehicle is parked on a flat surface and is stable prior to installation.

2. Place bag onto tunnel and open the hook and loop fastener panel on each side as shown.



3. Insert inner portion of bag in between the seat supports and under seat as shown.



4. Once bag is in position, secure into place by placing one hand inside bag and pressing outwards on the inner hook and loop fastener panel while pressing the outer hook and loop fastener panel inwards to ensure full contact with all portions of the hook and loop fasteners.





- 5. Repeat step 4 for opposite side fastener panel.
- 6. Ensure bag is fully secure.

# **FEEDBACK FORM**

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking **HERE** if viewing on a PC.

