

MIRROR KIT P/N 2877803



POLARIS
The Way Out.®

Application

Polaris Rush Snowmobiles

Before you begin, read these instructions twice and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This Kit Includes:

Qty	Part Description	Part Number
1	LH Mirror	2633932
1	RH Mirror	2633933
6	Screw	-----
6	Nylon Locking Nut	-----
1	Instructions	9922418

Tools Required:

1/4" Drill Bit	Torque Wrench
Drill	Hex Key Allen Wrench 5/32"
10 mm Wrench	

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence as shown on the attached instructions.

INSTALLATION INSTRUCTIONS

1. Using the Figure 1 for reference, locate mirror base to hood. (Note locator feature).
2. Use the drill and a 1/4 drill bit to drill out the center of the mounting hole.



3. Install the mirrors and secure with screws and nuts supplied with the kit. Torque to 6-8 in. lbs. (0.68-0.90 Nm) Figure 2.
NOTE: Brake duct may be removed to make the forward mirror fastener easier to install.

