

INDY RACK KIT

P/N 2879164



Application

My13 Indy 121

Before you begin, read these instructions twice and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This Kit Includes:

<u>Qty</u>	<u>Part Description</u>	<u>Part Number</u>
1	Rack	1019177
4	Carriage Bolt, 1/4-20 X 1	7512263
4	Washer, Flat, 0.28X0.750X0.062	7555859
4	Nut, 1/4-20 Nylok	7542122
1	Instructions	9924840

Tools Required:

7/16" Wrench or Socket

1/2" Open End Wrench

IMPORTANT: For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence as shown on the attached instructions.

APPROXIMATE ASSEMBLY TIME: 15 minutes

INSTALLATION INSTRUCTIONS

1. Place two carriage bolts in slots on each side of the tunnel. Figure 1.



Figure 1

2. Place rack over the bolts. Figure 2.



Figure 2

3. Slide rack and bolts forward until rack is snug to the seat.
4. Install washer then nut and tighten to bolts. Torque: 8 ft. lbs. (10.8 Nm). Figure 3.

