

TRAILER HITCH P/N 2876562



POLARIS
The Way Out.®

Application

All 2008 Polaris IQ and Switchback Snowmobiles

Before you begin, read these instructions twice and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

This kit includes:

Qty Part Description

- 1 Asm-Bumper Hitch 121/136 Blk - PN 1018128-067
- 6 1/4" nc x 3/4" Allen Socket Machine Screw
- 6 1/4" nc Nylok Nut
- 1 Instructions PN 9921400

Tools Required:

- 7/16" Open-end Wrench and Socket
- 5/32" Allen Key
- T-25 Torx Bit
- 17/64" Drill
- Drill Motor

IMPORTANT: Your Polaris accessory is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

INSTALLATION INSTRUCTIONS

1. Remove and discard the bolts retaining the existing rear bumper to the tunnel.
2. Position and fasten the trailer hitch onto the tunnel using four (two per side) 1/4" nc x 3/4" Allen socket machine screws and the 1/4" nc Nylok nuts into the front and rear holes.
3. Transfer drill the two remaining holes and fasten using the remaining 1/4" nc x 3/4" Allen socket machine screws and 1/4" nc Nylok nuts.

