

DRY BAG KIT



P/N 2883793;2883794

APPLICATION

Verify accessory fitment at Timbersled.com.

TIP

For optimal carrying capacity and organization, use Timbersled Dry Bags in conjunction with Timbersled Essentials Tunnel Bag PN 2883661 and/or Timbersled Sub-Frame Mounted Bag PN 2883650

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

KIT CONTENTS

This Kit includes: Qty. - 1 Dry Bag



NOTE

Both bags shown for REFERENCE ONLY.

REF	QTY	PART DESCRIPTION	KIT PN 2883793	KIT PN 2883794
1	1	Dry Bag - Small Dry Bag - Large	2883793 -	- 2883794
	1	Instructions		9929050

TOOLS REQUIRED

- None

CONSUMABLES REQUIRED

- None

IMPORTANT

Your Dry Bag Kit is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

ASSEMBLY TIME

Approximately 6 minutes

NOTE

Additional time may be required for optional steps, or to accommodate other installed accessories.

INSTALLATION INSTRUCTIONS

CAUTION

BEFORE STARTING INSTALLATION, always ensure vehicle is on a flat stable surface and is properly secured to avoid accidental tipping or other movement to prevent personal injury and/or damage to equipment. If applicable, turn key to "OFF" position and remove from vehicle.

1. Fill dry bag roughly half way from the top with items you wish to store and keep dry.

IMPORTANT

DO NOT overfill the bag. Doing so will prevent the bag from being rolled closed properly and may cause an improper seal.

2. Seal the dry bag top opening together by pressing upper rim hook and loop fastener panels together.



3. While holding the upper bag rim closed press down on dry bag to force any extra air out of the bag.

4. Next, roll bag rim down a minimum of three times in three consecutive 1 inch (25mm) increments to ensure proper seal.
5. Pull outer buckles in towards the center of the bag and clip firmly together.
6. Stow dry bag in Timbersled Essentials Tunnel Bag or Sub-Frame Mounted Bag for easy storage while riding.



FEEDBACK FORM

A feedback form has been created for the installer to provide any comments, questions or concerns about the installation instructions. The form is viewable on mobile devices by scanning the QR code or by clicking [HERE](#) if viewing on a PC.

FEEDBACK FORM

