

## CAN-AM X3 Striker Cage Install Instructions (CA162C032)

### TOOLS REQUIRED

- » SAFETY GLASSES/GLOVES/  
FLAME RESISTANT BLANKET
- » SAWZALL (RECIPROCATING SAW)
- » T27 TORX WRENCH
- » DRILL/DRILL BIT
- » TORQUE WRENCH
- » 17MM SOCKET/WRENCH
- » ALLEN WRENCH/SOCKET



1

Once Cage has been removed you will need to mask off the area around the plates with masking tape or painters tape and spray paint them so they don't rust.



2

Once the paint dries remove the tape and place the cab section of your new Pro Armor Striker cage into position on the mounting plates.



3

Use 16 m10 bolts and nuts supplied in the hardware pack and fasten cage to mounting plates at each pillar location (4). (washers not needed because both bolts & nuts are flanged!)



4

Torque the 16 Cage bolts to 50 lb. ft.



5

Now you are ready to install the rear section of the cage. You must install it to the cab section from the top first. Fasten with the 4 M8 Allen head bolts into both bungs.



You can now attach the lower part of the rear section to the car using the factory hardware. You will need to wiggle and adjust both rear wheels to align the bolts properly. Don't get frustrated this takes some patience! It helps to raise and lower the car with a jack until you get them aligned. You will not be able to get them all aligned at once so fasten the nuts one at a time until all 6 are on and lined up properly.



Torque all 6 bolts to factory specifications.



**⚠ WARNING**

**Improper Use of Off-Highway Vehicles Can Cause Severe Injury or Death**

**Be Prepared**

- Fasten seat belts.
- Wear an approved helmet and protective gear.
- [Reserved for message about other occupant restraint devices.]
- Each rider must be able to sit with back against seat, feet flat on floor (and foot rests), and hands on steering wheel or handhold(s), where equipped. Stay completely inside the vehicle.

**Be Sure Riders Pay Attention and Plan Ahead**

If you think or feel the vehicle may tip or roll, reduce your risk to injury:

- Keep a firm grip on the steering wheel or handholds and brace yourself.
- Do not put any part of your body outside of the vehicle for any reason.

**⚠ WARNING**

- **Never** stick hands, head or arms outside of vehicle at any time when it is in motion.
- **Always** wear and use proper safety equipment when using any Pro Armor product.
- Improper use of directions and/or product can result in injury to yourself or damage to your vehicle.
- **Disclaimer please read:** This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. The user assumes that risk. The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained.
- **Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.**
- If you have questions about your installation or are unable able to complete installation, contact Pro Armor Customer Service (888)312-7667 or have an authorized dealer or trained technician, inspect your installation.