



HONDA TALON DOOR BAG INSTRUCTIONS (H191Y329)

NOTE: Prior to installation, please verify if a revised version of this instruction sheet is available on proarmor.com.



1 Remove bolts from door panel then re-apply and tighten rear portion of door bag while holding in place as shown.



2 Remove factory bolt on stock door, lining up with the front mounting point of the door bag.



3 Using the same bolt removed in step 2, thread and tighten front portion of door bag.



4 Remove velcro backing and press firmly on door bag and repeat steps for opposite door.



⚠ WARNING

- Never stick hands, head or arms outside of vehicle at any time when it is in motion.
- Always wear and use proper safety equipment when using any Pro Armor product.
- Improper use of directions and/or product can result in injury to yourself or damage to your vehicle.
- **Disclaimer please read:** This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. The user assumes that risk. The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained.
- **Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.**
- If you have questions about your installation or are unable able to complete installation, contact Pro Armor Customer Service (888)312-7667 or have an authorized dealer or trained technician, inspect your installation.