



Polaris RZR XP1000/ 2015 900S Aluminum Roof (P141091)

Installation Instructions



Begin by removing any obstructions that may interfere with the installation of the roof. Place the supplied rubber strips [Item 1] strategically around the ROPS (circled in red), to eliminate any rattling noises.





- Place roof onto ROPS. Align slots on the roof to the mounting holes on the ROPS. Use the supplied M6 button head bolts, rubber washers, and nyloc flanged nuts to loosely fasten roof [Items 2, 3, and 4].
- Make sure the rubber washer is sandwiched between the roof and the ROPS. This will aid in eliminating metal on metal contact.
- Adjust the placement of the roof, making sure it is centered on the ROPS. Once you are satisfied, tighten down the fastening hardware. Installation is now complete. Make sure roof is secure before and after each operation of vehicle.

HARDWARE KIT

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	HDW00009	ADHESIVE BACKED NEOPRENE RUBBER_2"	8
2	HDWB0251	BOLT, M6 x 16MM, BUTTON HEAD FLANGE, BLACK ZINC	4
3	HDWN0008	NUT, M6 X 1.0 NYLOC FLANGED HEX	4
4	P141090-07	RUBBER WASHER	4

WARNING

Please read: This product is sold without warranty expressed or implied. No warranty or representation is made as to the products ability to protect the user / occupant from any injury or death in any manner of use. *The user assumes that risk.* The effectiveness of this equipment is directly related to the manner in which it is installed, used, and / or maintained. **Proper installation is solely the responsibility of the installer, and will not be assumed by Pro Armor.**

For further information on installation instructions and warnings please visit our website WWW.PROARMOR.COM or contact customer service at 1-888-31-ARMOR