



**HARDWARE KIT:**  
1- WINDSHIELD (FRONT OR REAR)  
4- HALF CLAMPS  
4- 16MM BOLTS  
4- NYLOC NUTS  
1- WEATHER STRIP

**TOOLS REQUIRED:**  
» 4MM ALLEN SOCKET  
» 10MM SOCKET  
» T40 TORX FOR INTAKE COVERS IF YOU HAVE A TURBO CAR

## Front WindShield Instructions (P141W460/P141W462/P144W460/ P144W462)



1

Apply provided weather strip to bottom of front windshield frame.



2

Remove half clamps (2) on front of roof to allow space to insert windshield. Located on each side of roof.



3

Using Included half clamps, hand tighten clamps to both sides for the lower portion of windshield for ease of install.



4

Slide front windshield in between the roof and cage.



5

Replace the half clamps you removed in step 1 and torque down the bolts securing windshield to the cage at all four corners.



**WARNING**  
Improper Use of Off-Highway Vehicles Can Cause Severe Injury or Death

**Be Prepared**

- Fasten seat belts.
- Wear an approved helmet and protective gear.
- (Reserved for message about other occupant restraint devices.)
- Each rider must be able to sit with back against seat, feet flat on floor (and foot rests), and hands on steering wheel or handholds (where equipped). Stay completely inside the vehicle.

**Be Sure Riders Pay Attention and Plan Ahead**

If you think or feel the vehicle may tip or roll, reduce your risk to injury:

- Keep a firm grip on the steering wheel or handholds and brace yourself.
- Do not put any part of your body outside of the vehicle for any reason.