

## POLARIS SNOW MAINTENANCE CHECKLIST

|                                |   | EV.           | START OF<br>SEASON | MID-<br>SEASON | END OF<br>SEASON | SEE<br>DEALER |
|--------------------------------|---|---------------|--------------------|----------------|------------------|---------------|
| SYSTEM                         | ACTION  | EVERY<br>RIDE | SON OF             | MID-<br>ASON   | SON OF           | EE SEE        |
| FRONT SUSPENSION               | Check for damaged bushings, struts, linkage, springs              |               | X                  | X              |                  |               |
| RAIL SLIDERS                   | Check for wear  |               | X                  | X              |                  |               |
| REAR SUSPENSION / IDLER WHEELS | Check for damage, loose wheels, grease/lubricate                  |               | X                  | X              |                  |               |
| FLUID LEAKS                    | Coolant, engine oil   | X             |                    |                |                  |               |
| RECOIL                         | Verify operation, rope  |               | X                  |                |                  |               |
| CVT                            | Inspect belt, cover, clutches                                     |               | X                  | X              |                  |               |
| FUEL LINES                     | Check routing, damage   |               | X                  | X              |                  | X             |
| HEADLIGHT/TAILLIGHT            | Verify operation  | X             |                    |                |                  |               |
| STEERING                       | Check for damage, excessive play                                  | X             |                    |                |                  |               |
| EXHAUST                        | Check for leaks, loose shields                                    |               | X                  | X              |                  |               |
| HANDLEBARS/GRIPS/CONTROLS      | Verify operation  | X             |                    |                |                  |               |
| BRAKES                         | Inspect disc/pad Wear   |               | X                  | X              |                  |               |
| SKIS/CARBIDES                  | Check for wear  | X             | X                  |                |                  |               |
| TRACK                          | Inspect for torn or missing lugs, studs, clips, alignment/tension |               | X                  | X              |                  |               |
| SNOWFLAP                       | Check mounting  | X             |                    |                |                  |               |
| TUNNEL COOLING                 | Inspect for damage  |               | X                  |                |                  | X             |
| RADIATOR                       | Check for damage (if equipped)                                    |               | X                  |                |                  | X             |
| COOLANT HOSES                  | Check hoses, clamps   |               | X                  |                |                  | X             |
| AIR/SNOW FILTER                | Verify clean and dry  |               | X                  |                |                  |               |
| LOOSE HARDWARE                 | Inspect fasteners   |               | X                  |                |                  | X             |
| MASTER CYLINDER                | Verify fluid level  | X             |                    |                |                  |               |
| COOLANT                        | Verify level  | X             |                    |                |                  |               |
| ENGINE OIL                     | Verify level (if applicable)                                      | X             |                    |                |                  |               |
| CHAINCASE OIL                  | Verify level / metal in oil                                       |               | X                  |                |                  | X             |
| SPARK PLUGS                    | Verify condition  |               | X                  |                |                  |               |
| FUEL TANK                      | Add fuel stabilizer   |               |                    |                | X                |               |
| SHOCKS                         | Rebuild   |               | X                  |                |                  | X             |
| CARBURETOR                     | Clean   |               | X                  |                |                  |               |

SEE DEALER FOR ADDITIONAL MAINTENANCE INFORMATION.