

POLARIS PRO XD™ | PLOW SYSTEM

Do more with your PRO XD year-round by adding a plow system to move snow during the winter months and move dirt and gravel during the summer months. Choose between a steel or poly plow:

STEP 1: PLOW MOUNT	STEP 2: FRAME MOUNT	STEP 3: HYDRAULICS <i>(OPTIONAL, NOT REQUIRED)</i>	STEP 4: PLOWS
<p>2883255 This heavy-duty mount plate installs on a PRO XD and serves as the foundation of the Glacier® Pro Plow System. The plow frame (sold separately) attaches to this plate whenever the plow is to be used.</p>	<p>2879106 This Glacier® PRO HD Plow Frame serves as the strong and flexible core of the Glacier® Pro Plow System. This heavy duty push frame installs on the mount plate (if applicable) installed on the vehicle, and the plow blade (sold separately) attaches to this push frame.</p>	<p>2883410 HYDRAULIC LIFT SYSTEM</p> <hr/> <p>2889029 HYDRAULIC ANGLE SYSTEM</p> <hr/> <p>2883247 CONTROLLER (required for hydraulic components)</p>	<p>2879874 – 72" STEEL BLADE 72" steel plow blade with wear bar</p> <hr/> <p>2879317 – 72" POLY BLADE 72" poly plow blade with wear bar</p>



PART #S, DESCRIPTIONS, AND PICTURES ARE SUBJECT TO CHANGE WARNING: Polaris PRO XD vehicles can be hazardous to operate and are not intended for on-road use. All riders should always wear head protection - such as hard hats or a helmet - that is appropriate for operating conditions and intended usage, considering factors such as intended speed, unevenness of terrain, turns in path, weather, obstacles, and other traffic. Always use seat belts and close doors (as equipped). Never engage in stunt driving, and avoid excessive speeds and sharp turns. Riding and alcohol/drugs don't mix. All riders should take a safety training course. Call 800-342-3764 for additional information.
©2019 Polaris Industries Inc. P#9948033

**FOR MORE INFORMATION VISIT
[POLARIS.COM/COMMERCIAL](https://www.polaris.com/commercial)**