



Polaris Rhino Grip Instruction Manual

P/N 2881574

REF	PART DESCRIPTION	QTY
1	Rhino Grip XL	2
2	Rhino Grip Base	2
3	Kwik Clip	2
4	Nylon Washer	2
5	Large Rubber Expander	2
6	Plastic Spacer	2
7	Small Rubber Expander*	2
8	Threaded Rod	2
9	Rubber Strap	2
10	Thumb Screw	2

ASSEMBLY:

1. Place the smaller rubber expander on the threaded rod.
NOTE: The rubber expander for both systems has a counter-bored relief that mates to the threaded rod. Please be sure to install correctly!
2. Slide the plastic spacer onto the threaded rod.
3. Slide the larger rubber expander onto the rod.
4. Place the nylon washer on top of the large rubber expander and thread the rod into the threaded insert in the bottom of the base.
5. Place the expander in the Lock & Ride® hole on the bed rail and twist the base clockwise. As you twist the threaded rod will compress the rubber expanders and secure the grip to your Polaris Ranger.
6. Place the Rhino Grip into the base, orient the grip as desired and secure with the Kwik Clip.
7. To remove, simply turn the base counter clockwise and remove from the bed rail.

