



## WIRING

All wires and connections should be secured and away from any moving parts or extremely hot surfaces. Additionally, they should be properly fused and protected from water, mud and other outdoor elements.



Congratulations on your choice of Pro Armor Sound Bars. This "Quick Start" Installation guide is meant to help you complete a basic installation. For more detailed information about the product, please visit our website at [ProArmor.com](http://ProArmor.com)

## WIRING & FUSING

All Pro Armor powered audio accessories require installation. We highly recommend that you follow this guide as a minimum. If your machine is longer, you may want to go 1 gauge thicker on your wiring for Power and Ground.

You should never connect your Power and Ignition wires together. When you do this, the power on your unit, never turns off and you can damage product and wear down your battery. A water proof fuse should be installed up high in the machine to avoid water and mud.

## WIRE GAUGE & FUSE REQUIREMENTS

| Model              | Power/Ground Wire | Turn On Wire | Fuse  |
|--------------------|-------------------|--------------|-------|
| Sound Bar 8        | 10 gauge          | 18 gauge     | 15Amp |
| Sound Bar 4        | 12 gauge          | 18 gauge     | 10Amp |
| Power Speaker Pods | 10 gauge          | 18 gauge     | 20Amp |

## MOUNTING PRECAUTIONS

After installing any Pro Armor audio products and before each ride make sure that the units are properly secured. The last thing you want to do is injure yourself or your audio equipment while out on the trails. Be mindful that these products may need to be re-torqued (tightened) after an intense ride.

## CLEANING PRECAUTIONS

It is very important to note when cleaning your Pro Armor audio products to never use high pressure washers found at self-serve car washes or "power washers". If you would not put the water pressure on your skin, DO NOT put it on your speakers or electronics.

It is ok to use a low pressure gentle stream hose, quickly. Like a garden hose set for lowest pressure. Regarding cleaners or cleaning products. Make sure to use a diluted non-corrosive cleaning product. These can be found at your local automotive parts store in the car wash soap section. If you have heavy or dried on dirt and mud you should use a soft brush or soft cloth to loosen the dirt.




**NO PRESSURE WASHER  
NO CHEMICAL CLEANSERS**



## Controls

- 1 Power - Will turn the unit on or off. / Three second press will switch audio inputs.
- 2 PLAY / PAUSE - Press once to pause. Press again to play.
- 3 Volume DOWN - Each press will decrease the volume.
- 4 Volume UP - Each press will increase the volume.
- 5 Track DOWN - Press to restart the current track or to back up to previous tracks.
- 6 Track UP - Press to advance to the next track.



## Bluetooth Device Pairing

The pairing process can vary based on your particular device. Refer to the operating instructions of your device. Below is the general process to connect.

The Pro Armor Sound bar unit can be powered on either with the power button or with the orange remote turn on wire.

During unit power up, the blue LED on the left of the control panel will blink indicating that it is in Bluetooth search mode.

During this process "PRO ARMOR" should show up in your list of Bluetooth devices when the search has connected with your device. When the connection is made the blue LED will change to solid.

Once a device has been paired the unit will reconnect at power up if the device is in range.

To connect to a different device, the first device will need to be disconnected.


When a phone call is received, the audio signal will mute but not disconnect.

To switch to 3.5mm press the power button for three sec.

To switch back to BT press the power button again for three sec.



## Operators Guide



## Pro Armor Sound Bars