

# MAINTENANCE SCHEDULE

Check your owner's manual for additional recommended service items and vehicle-specific timing.

**800**  
km

**AIR FILTER:**  
INSPECT & REPLACE  
IF NECESSARY

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**COOLANT, BRAKE &  
CLUTCH FLUID:**  
CHECK LEVEL  
REPLACE AS NEEDED

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**8,045**  
km

**AIR FILTER:**  
INSPECT & REPLACE  
IF NECESSARY

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**16,093**  
km

**AIR FILTER:**  
INSPECT & REPLACE  
IF NECESSARY

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**BRAKE FLUID:**  
REPLACE

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**24,140**  
km

**AIR FILTER:**  
REPLACE

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**BRAKE & CLUTCH FLUID:**  
CHECK LEVEL  
REPLACE AS NEEDED

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**32,186**  
km

**AIR FILTER:**  
INSPECT & REPLACE  
IF NECESSARY

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**BRAKE FLUID:**  
REPLACE

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**40,234**  
km

**AIR FILTER:**  
INSPECT & REPLACE  
IF NECESSARY

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**DRIVE BELT:**  
INSPECT, ADJUST  
TENSION & REPLACE  
IF NECESSARY

**ENGINE OIL:**  
CHANGE

**48,280**  
km

**AIR FILTER:**  
REPLACE

**BATTERY:**  
CLEAN TERMINALS &  
CONNECTIONS  
MAINTAIN CHARGE WITH  
BatteryMINDer®

**BRAKE & CLUTCH FLUID:**  
REPLACE

**DRIVE BELT:**  
REPLACE

**ENGINE OIL:**  
CHANGE