



Tech Support: (844) 378-8143 technicalservice@apexproductgroup.com

## VAPOR LOW VOLTAGE TACHOMETER SENSOR INSTALLATION

## LOW VOLTAGE TACHOMETER SENSOR INSTALLATION:

- 1. Remove the Coil Input spade connector from the coil.
- 2. Replace the coil input spade connector, crimping the positive tach+ lead in between the coil spade and coil input connector.
- 3. Connect negative tach- lead to the frame ground.





## LIMITED WARRANTY