

REAR RACK KIT



P/N 2879717


APPLICATION

MY14 to Current Sportsman Models

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for in package. Please retain these installation instructions for future reference and parts ordering information.

KIT CONTENTS



REF	QTY	PART DESCRIPTION	PART NUMBER
1*	2	Flange Hex Screw 1/4-20	-
2*	6	Flange Hex Screw M6 x 60 mm	-
3*	4	M6 Flat Washer	-
4	1	Rear Welded Rack Extender	-
		Instructions	9925004

Items marked (*) are included in Hardware Kit PN 2205227.

TOOLS REQUIRED

- 3/8" or 10 mm Standard or Metric Wrenches or Sockets
- Torx 27 Socket

ASSEMBLY TIME


10 minutes

IMPORTANT

Your Polaris REAR RACK KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

INSTALLATION INSTRUCTIONS

1. Remove and discard the six machine screws (A) and four original nuts holding the tubes to the rack.




NOTE

Assemble all hardware before tightening rack extender.

NOTE

MY14 models use M6 screws and MY15 and newer models use 1/4-20 screws for installing in the center of the rack extender. Make sure to check the screws right for the machine and replace the screws with new screws if required.



2. Assemble two 1/4-20 Hex screws ① or M6 screws ② in the center of the rack extender.
3. Install the remaining four M6 x 60 mm hex screws ② with M6 washers ③ on the outer corners of the rack extender ④.
4. Tighten all screws.

