

ROCK SLIDER KIT



P/N 2881992

APPLICATION


Verify accessory fitment at Polaris.com.

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	Rock Slider, LH Front	1022491
2	1	Rock Slider, RH Front	1022492
3	1	Rock Slider, LH Rear	1022493
4	1	Rock Slider, RH Rear	1022494
5*	8	Wedge, Expansion Anchor	5632958
6*	8	Tube, Expansion Anchor	5337853
7*	8	Washer - 0.327 X 0.875 X 0.090	7556341
8*	8	Screw, Hex Flange - M8 X 1.25 X 30	7518884
9*	8	Plug	5450653
10*	4	Screw, Socket Head - M10 X 1.5 X 25	7517358
	1	Instructions	9927093

Items marked (*) are included in Hardware Kit PN 2206314.

TOOLS REQUIRED

- Safety Glasses
- Socket Set, Metric

- Torque Wrench

IMPORTANT


Your ROCK SLIDER KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.

ASSEMBLY TIME

Approximately 30 minutes

INSTALLATION INSTRUCTIONS


1. Place vehicle in "PARK". Turn key to "OFF" position and remove from vehicle.
2. Loosely assemble LH front and LH rear rock sliders ①③ using two screws ⑩ as shown.



3. Guide rock slider assembly into position so that all four expansion anchor assemblies ⑤⑥⑦⑧ fully engage vehicle frame mounting holes as shown.

IMPORTANT



Rock slider must be firmly seated against vehicle frame at all four locations before tightening screws. Anchor assemblies are not intended to draw slider and frame together.



4. Ensure expansion anchors are fully seated by slowly rotating each anchor assembly ⑤⑥⑦⑧, verifying that flat faces of tube ⑥ have slipped into and aligned with flat faces of welded socket (A) as shown.

IMPORTANT

Failure to properly align anchor flats will result in incomplete fastener engagement and improper torque application.



5. While ensuring rock slider is firmly seated against vehicle frame, and anchor flats are properly aligned, tighten four screws ⑧. Torque to specification.

TORQUE

16 ft. lbs. (22 Nm)

NOTE


After anchor begins expanding repositioning may become difficult.

6. Torque two screws ⑩ installed in Step 2 to specification.

TORQUE

40 ft. lbs. (54 Nm)

7. Insert four plugs ⑨ into slider as shown.



8. Repeat Steps 2–7 for RH side using front and rear rock sliders ② and ④.