

POLY REAR PANEL KIT PN 2878752



Application Polaris RZR

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

QTY.	Part Description	Tools Needed
1	Rear Panel	T25 Torx Driver
3	Large Snap Clamps	Flat Head Screwdriver
2	Small Snap Clamps	
10	Screws	
2	Rubber Grommets	

(Arrow points to inside of vehicle.)




Fig. 1

IMPORTANT: Your Polaris accessory kit is exclusively designed for your Polaris vehicle. Please read the installation instructions and operator's manual thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris. **Approximate Installation Time:** 30 Minutes

INSTALLATION INSTRUCTIONS

Note: Do not use a power drill to assemble the rear panel.

1. Refer to Fig. 2. Align (3) large snap clamps with the mount holes on the inside of the rear panel. The snap clamps should be aligned so the hook portion is facing the inside of the vehicle, as shown in Fig. 1. Loosely fasten the snap clamps to the rear panel using (6) screws.
2. Align (2) small snap clamps with the mount holes on the inside of the rear panel. The snap clamps should be aligned with the flat portion facing the inside of the rear panel as shown in Fig. 1. Loosely fasten the snap clamps to the rear panel using (4) screws.
3. Insert (2) rubber grommets through the underside of the holes on the bottom of the rear panel. Push the grommet through until the top has gone completely through the rear panel. You may need to use a flat head screwdriver to pry the grommet all the way through.
4. Align the rear panel with the rear frame of the RZR vehicle, and the rear panel grommets with the holes in the RZR box. Press the snap clamps onto the frame bars. Squeeze the large snap clamps once they are installed on the frame to ensure they have been snapped in place.
5. Tighten all hardware once desired fitment is reached.

IMPORTANT: Do not use glass cleaners and solvents such as ammonia, alcohol, and petroleum distillates.

Maintenance: Periodically check all fasteners for tightness and re-torque as required.

Cleaning:

1. Use an indirect high pressure water supply to rinse the large dirt particles from the rear panel.
2. Once the majority of dirt is removed, use warm soapy water and a cotton terry cloth to wash all rear panel components.
3. Rinse thoroughly and allow to air dry.
4. Use a quality polish such as Plexus® or Novus II® to clean and remove fine scratches from the rear panel.

