

LOWER HOOP ACCENT KIT



SLINGSHOT

P/N 2882419

APPLICATION

Slingshot

BEFORE YOU BEGIN

Read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.


DISCLAIMER ACCESSORY WEIGHT

When adding accessories, equipment, passengers and luggage to your vehicle, do not exceed the total weight capacity of the vehicle or of the front or rear axle (GVWR or GAWR as indicated on the Safety Compliance Certification label). Ask an authorized dealer for specific weight information if you need assistance. It is the owner's responsibility to use the Polaris Slingshot Accessories website as a tool for limiting the amount of accessories, based on maximum allowable vehicle weight requirements. It may be a violation of the Clean Air Act or the NHTSA regulations to disregard these requirements. For a complete listing of the accessories that are available for your vehicle, please contact your authorized dealer or visit the online store web site:

Web Address (United States): <http://www.polaris.com/en-us/slingshot/shop/accessories>.

KIT CONTENTS

This Kit includes:



REF	QTY	PART DESCRIPTION	PART NUMBER
1	1	Front Hoop Cover, RH	5450029
2	1	Rear Hoop Cover, RH	5450031
3	1	Rear Hoop Cover, LH	5450030
4	1	Front Hoop Cover, LH	5450045
	1	Instructions	9927683

TOOLS REQUIRED

- Torque Wrench
- Safety Glasses
- T40 Torx®
- T25 Torx®

IMPORTANT

Your LOWER HOOP ACCENT KIT is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety, and to ensure a satisfactory installation, perform all installation steps correctly in the sequence shown.


ASSEMBLY TIME

Approximately 20 minutes


INSTALLATION INSTRUCTIONS

REMOVAL


1. Put the transmission in "NEUTRAL" and turn the key to the "OFF" position. Remove the key from vehicle. Apply the parking brake.
2. Start with the driver side. Using T25 Torx® drive remove two screws (A) located at the top front of the lower roll hoop cover (B). Retain screws for later use.




3. Using T40 Torx® drive remove two screws (C) located at the lower front of the lower roll hoop cover (B). Retain screws for later use.



4. Using T40 Torx® drive remove two screws (C) located at the lower back of the lower roll hoop cover (D). Retain screws for later use.




5. Remove lower roll hoop covers (B) and (D) around the roll hoop (E).




6. Repeat Steps 2-5 for the passenger side.

INSTALLATION


1. Starting with the driver side, install the new lower roll hoop covers ③ and ④ around the roll hoop (E).




2. Ensure two lower roller hoop cover ③ and ④ halves are aligned to each other as well as screw holes are aligned with roll hoop (E).




3. Using T25 Torx® install two retained screws (A) at the top of lower roll hoop covers ③ and ④. Do not fully tighten.



4. Using T40 Torx® install two retained screws (C) at the bottom of lower roll hoop cover ④. Do not fully tighten.




5. Using T40 Torx® install two retained screws (C) at the bottom of lower roll hoop cover ③. Do not fully tighten.



6. Once again check for fit of lower hoops. Ensure both sides fit flush.

7. Tighten two top screws (A) using T25 Torx®.



8. Tighten four lower screws (C) using torque wrench and T40 Torx® to specification.

9. Repeat Steps 1-8 for passenger side.

TORQUE

65 in. lbs. (7.34 Nm)

